



This package includes:
 1 Pet
 1 Shell
 1 Small Friend
 2 AG13(LR44) batteries

Please Note
 • Please retain these instructions as they contain important information.
 • Read all of the instructions before operating your pet.
 • Adult supervision is required to change the batteries.

• The Xia-Xia™ pet is a toy. It is not intended for use with live animals.
 • Xia-Xia™ pets come in many different colors and styles and may differ from the pet shown on this instruction sheet.


• Remove all contents from package and discard any rubber bands, wire ties or other packaging materials that are not part of the product.


CAUTION To prevent entanglement, keep hair away from wheels.

IMPORTANT! ADULT SUPERVISION AND ASSISTANCE MAY BE REQUIRED ON ASSEMBLY


Changing the Batteries

- On the back of the pet, unscrew the battery hatch
- Replace the 2 batteries matching the polarity shown inside the battery compartment.
- Replace the battery hatch and screw snug.


Replace with 2  AG 13(LR 44) Button Cell batteries



The Xia-Xia™ pet has a power switch on the bottom. Move the switch to the ON position.



To activate the Xia-Xia™ pet tap either claw. This will cause the pet to run for a short time. Normal activation time is 3 to 5 seconds. To make the pet run longer, press and hold the claw for 1 second. This will make the run time about 15 seconds.




When the pet is active, the claws work as a bump sensor. The pet will back up when it hits an obstacle. When not active, the pet will go into a low power mode. To further conserve battery life turn the ON/OFF switch to OFF when not in use.

The snap on shell is removable and contains a small friend collectible.

The collectible small friend can be attached on the outside of the shell by placing it on the post located on the front edge of the shell.

All Xia-Xia™ shells fit all Xia-Xia™ pets. Additional shells are sold separately.



BATTERY INFORMATION

- Always replace used batteries with fresh Alkaline batteries. Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Do not mix old batteries with new, do not mix Alkaline with standard carbon zinc or rechargeable nickel cadmium batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries are to be removed from the toy.
- Do not dispose of batteries in fire.
- The supply terminals are not to be short-circuited.

Claim: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For questions and comments please call in the U.S.A. and Canada 1 800 225 9319

Xia-Xiapets.com



©2011 Cepia LLC.
 St. Louis Missouri 63124
 Made in China

WARNING:
 CHOKING HAZARD - Small parts
 Not for Children Under 3 Years



Complies with Toy Safety Standard ASTM F963 Please Recycle

WARNING:
 All rubber bands and wire ties, as well as tags, are not parts of this toy and should be discarded for your child's safety. Colors and contents may vary from those shown on the package.

Printed in China

R 090811 87000