miTech™

P.C. Gizmo™

He makes using your computer even more fun!

Age: 8+
mi Tech P.C. Gizmo
The Funniest PC Helpers!

Congratulations on your purchase of the miTech P.C. Gizmo! It is a perfect companion to kids and teenagers who use computers. P.C. Gizmo is not only easy and fun to play with, it is also very useful as it helps you to manage your communications applications on your computer such as email, instant messengers, and Internet calling.

In the Box
1 P.C. Gizmo unit with USB cable
1 CD-ROM with PC Gizmo software and User Manual
1 Quick Start Guide

Computer Requirements
- Microsoft Windows XP/Vista compatible
- Pentium III 866MHz or higher
- 500 MB free hard disk space (1 GB recommended)
- 128 MB RAM

Applications Supported
- AOL AIM v5.9 and v6.5
- Yahoo Messenger v8.1
- Windows Live Messenger v8.1
- Skype v3.6

b2™ www.b2stuf.com

Cautions for Installation

For Windows users:

Important:

- Make sure you have a backup for everything on your computer before you install PC Gizmo.
- P.C. Gizmo is tested and is recommended to use on English Windows OSs only.
- DO NOT connect P.C. Gizmo to your computer before completing its software installation.
- During installation, you may be requested to insert your Windows Setup CD. Remove the P.C. Gizmo CD and insert the Windows Setup CD into the CD-ROM drive. Remove it when you are notified that installation is complete.

Installation

1. Close all active software applications.
2. Insert P.C. Gizmo installation CD into the CD-ROM drive.
3. P.C. Gizmo setup will start if auto-run is enabled.
4. If auto-run is disabled, select CD-ROM drive, and then double click the installation icon. (File name: P.C. Gizmo Installer.exe)
5. P.C. Gizmo Setup Wizard will guide you through the setup process.

P.C. Gizmo Setup Wizard

1. Press NEXT on the welcome page.

2. Click ‘I Agree’ on accepting the license agreement to continue.



3. Click WinPcap check box if it is the first time installation and then press NEXT.



4. Enter your desired P.C. Gizmo folder name in Start Menu. Simply click NEXT if you let Wizard specify the default folder.

5. Enter your desired directory for P.C. Gizmo folder. Simply click NEXT if you let Wizard specify the default directory. If you want to change anything you have entered, click BACK.



6. When you are required to install WinPcap click “NEXT” on the WinPcap’s welcome page. If WinPcap is not selected in step 3, goes to step 9.



7. Click “I Agree” on agreeing with license terms



8. Click FINISH when WinPcap installation is completed.



9. The computer will then continue to install P.C. Gizmo software. Click FINISH to close the wizard.



10. A P.C. Gizmo icon will then be shown on the desktop.

Quick Start Guide

1. Now connect the USB cable of PC Gizmo to your computer.



2. P.C. Gizmo product will be turning, rocking with flapping ears and a short tune sound effects and light patterns.

3. Double click the P.C. Gizmo icon on the desktop of your computer.

4. A virtual Gizmo will appear on the screen.

5. Right click on the virtual Gizmo to open dialogue box and then left click to select CONFIGURATION to show configuration page.

6. Now, your P.C. Gizmo is ready to serve you.

7. To find out more what PC Gizmo can do for you, browse through **P.C. Gizmo Kid-Friendly Instruction Manual** below

P.C. Gizmo
Kid-Friendly Instruction Manual

Hi, I am PC Gizmo. I live OUTSIDE your computer.

Hi, I am Virtual Gizmo. I live INSIDE your computer.

We are your PC Helpers!

Operating the P.C. Gizmo

Accounts Setup

Before I can help you, first you need to set up accounts. Right click on Virtual Gizmo to open menu and Left click to select CONFIGURATION PANEL. You will find a page to enter you account information for email [Hotmail, Yahoo Mail, or POP3 servers], instant messengers [AIM, MSN, or Yahoo Messenger] and Internet phone-Skype. If you do not know about them, find out from your parents or friends.

Email

Click on the Email tab. You need to type in your user IDs and your passwords. I need this information to help you checking up to 2 email accounts.



Instant Messenger

Click on the Instant Messenger tab. You need to type in your user IDs and your passwords. I need this information to help you handling up to 2 Instant Messenger accounts.



Internet Call (Skype)
Click on the Internet Call tab. You need to type in your user ID and your password. I need this information to help you using Skype.



General Setup
You can adjust my voice by clicking on the General tab. Then choose how you want me to alert you. I can speak in Cyber or Cuteness mode.



Saving Information
Remember to click SAVE after you have finished entering account information or after you have changed them! Do the same for sound effects.

 **Virtual Gizmo**

Let Me Help
Email
I will automatically check if there is any new mail. If there is, you will find a mailbox displayed next to me. You will also see above me the email icon. The red email light will also be lit on PC Gizmo's body. The mailbox icon will indicate if you have lots of mail or not.

But once I have made this alert, I won't remind you again until some new mail comes in. You can control how often I check mail by right clicking over my body to open the CONFIGURATION PANEL. Click on the Email tab to enter how frequently you want me to check your mail for you. Usually, I check mail for young people once in between 5 minutes to 10 minutes.

Instant Messengers
I'll also notify you when there are incoming messages from a user from your Instant Messengers.

When there is a new message, you will see above me the message icon. The green message light will also turn-on on PC Gizmo's body.

Skype
When there is a new incoming call from Skype, I'll let you know too. I'll do that by showing above me the Skype icon. You will find the yellow Skype light turned-on on PC Gizmo.

The icon above me will also tell you if there are MISSING calls or REJECTED calls.

Remember that when you are using PC Gizmo with Skype the first time, a window will be displayed, and you will be asked if you will let me connect to Skype. Just click on ALLOW.

Short Cuts
I can also do short cuts for you to open your communication applications. Just move the mouse pointer over my body. Then you will see 3 buttons rolling out from my right or left side. Mouse over the red email button and a dialogue box will show. Click on the account of your choice and internet browser will open your web email applications. You can do the same for Instant Messengers and Skype.

Play with Me

Playing
Double click on me. You will find me doing something cute or funny for you. I may jump, escape, laugh, ping-pong, tickle, replicate myself, or dance. Play with me and you will find out!



Falling
Drag me up from where I am to a higher position on the screen, I'll fall down to my original position. But if you really want to move me to higher position on the screen, you have to do this bit by bit.

Rolling
I am good at rolling too. Put me on any window top I'll roll along the window or roll down from the side. Which side? Try it!



Duplicating
Sometimes, I can duplicate myself to make b2 logo.



Floating
Some people want to see me all the time and do not want to see me covered by other windows or icons. You can do that by opening the CONFIGURATION PANEL, then choose the General tab and click on Always On Top.



P.C. Gizmo

Computer Sleeping
I am most useful when your computer is asleep and you cannot see Virtual Gizmo. But I'll remain awake. The lights on my body will tell you if you have received email, instant messages, or Skype calls. I'll flap my ears and dance around if I receive something new.

Computer Awake
When your computer is awake and you can see Virtual Gizmo, like twins, I'll do what Virtual Gizmo does. I'll let you know about incoming email, instant messages, and Skype calls.

Let me Help
There is a button on my head. You can press it and hold to get me to check your email. Under me, you will find buttons to control how loud I make sound and a button to RESET when something goes wrong.

Play with Me
Press the button on my head when you are bored. I'll dance for you!

Set up for Wireless Network Interface

1. Open Network Connections.
2. Under **LAN or High-Speed Internet**, hold down the CTRL key, and then click the wireless adapter and the Ethernet adapters that you want to include.
3. Right-click one of the connections that you have selected, and then click **Bridge Connections**.

Trouble-Shooting Guide

Problem	Cause	Solution
No response when connecting the device to PC	Improper connection	Re-connect the USB cable
	Failed USB port	Connect to another USB port
No response when connecting the device to USB hub	Not enough power from USB hub	Use USB hub with external power adapter
		Connect to PC directly
Incorrect response after checking email	Incorrect Yahoo Mail/Hotmail account setting	Check and correct email account setting, login name and password
	Incorrect pop3 account setting	Check and correct the pop3 account setting
No response on instant messenger communication	Improper setup of IMs (AIM, YM and MSN)	Check and correct the IM account setting
No response on Skype call	No access to Skype	Refer to FAQ's Q1 in the manual
No sound from the device	Sound is disabled	Go to configuration menu, select general setting page, enable the sound.
No sound on the responses in PC	PC's speaker volume is low or muted	Set PC's speaker volume to appropriate level
	PC sound is disabled	Go to configuration menu, select general setting page, enable the sound.
Cannot install the software	Do not have the access right to install program	Change the user account type to Administrator

Frequently Asked Questions

Q1. No alert when there is incoming call from Skype.
A1. Check if P.C. Gizmo is allowed to access to Skype.
1. Open **Options** page of Skype and go to **Advanced Settings**, click the "**Manage other programs**' **access to Skype**" option.
2. Change the access right if P.C. Gizmo is not allowed to use Skype.

Q2. Get following warning message about accessing to Skype.



A2. Refer to the answer of Q1.

Q3. Sometimes, there is no or extra response of P.C. Gizmo on AIM 6.5 communication.
A3. User may experience this and it is normal to the software.

Q4. There is no response of P.C. Gizmo on instant messenger communication even the setup of user account and password is correct.
A4. If the connection to internet goes through proxy server, it is the limitation of the software to get no response.

Q5. No email alert for Hotmail account even though there are new emails.
A5. Check if Hotmail account is in Classic version. If not, change it in **Options** of Hotmail.

Q6. After changing network configuration such as enabling or disabling bridge connection for wireless network, there is no response of P. C. Gizmo or the program cannot be started.
A6. Re-start the computer can solve the problem.

Other Information

Disclaimer and Limitation of Liability

Blue Box and its suppliers assume no responsibility for any damage or loss resulting from the use of this product. Blue Box and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. Blue Box and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery or repairs. Be sure to make backup copies of important data on other media to product against data loss.

Important Legal Information

The copying of the P.C. Gizmo software is illegal and is strictly prohibited by domestic and intellectual property law. “Back-up” or “archival” copies are not authorized and are not necessary to protect your software. Violators will be prosecuted.

This software is not designed for use with any unauthorized copying device or any unlicensed accessory. Use of any such device will invalidate your product warranty. Blue Box is not responsible for any damage or loss caused by the use of any such device.

Regulatory Information

FCC Notice
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

BLUE BOX US ADDRESS:

Blue Box USA
220 South Orange Ave
Suite 106
Livingston, NJ 07039
Tel: (973) 740-8882
Fax: (973) 740-2323

Microsoft, Windows, Hotmail, MSN are registered trademarks of Microsoft Corporation in the United States and other countries. AIM is a registered trademark of AOL LLC. Yahoo! is a trademark of Yahoo! Skype is a registered trademark of Skype Limited. All other service marks, trademarks or registered trademarks are the property of their respective owners.

© 2008 Blue Box. All Rights Reserved. b2 logo, miTech and P.C. Gizmo are trademarks or registered trademarks of Blue Box in the United States and in other countries.